



TWO WAYS TO ORDER BIMINI TOPS, FRAMES AND FABRIC

Frame, Fabric, & Boot Separates ship in individual packages

- Help reduce inventory
- Shippable via UPS

Pre-Assembled Bimini Top Packages shipped ready to install

- Help eliminate assembly labor

Bimini Top Frames

- Frames have multiple bow construction for strength and rigidity
- Main support legs have 7/8" diameter double wall aluminum tubes for extra strength and stability
- Pontoon frames are made of quality 1" square aluminum tubes to match the rail sizes of today's popular pontoon boats
- All mounting hardware is included



Bimini Top Fabrics

Double needled seams are sewn 4-ply for extra strength with no exposed raw edges. Quality needle work and stitching thread help resist leakage along the seams.



Premium Sunbrella Brand Acrylic Fabric

- The industries most trusted fabric
- Fabric won't fade, harden, crack, peel, or be affected by outdoor exposure
- The woven solution dyed acrylic is easy to clean and won't trap heat or moisture
- Superior color-fastness and fade-resistance because color is impregnated in the yarn
- Outstanding stain-resistance and cleanability
- Long lasting UV-resistance



Fabric colors and Color Codes

GRAY ACRYLIC: GY	BEIGE ACRYLIC: BE	GREEN ACRYLIC: GN	BLACK ACRYLIC: BK	RED ACRYLIC: RD
BLUE ACRYLIC: BL	NAVY ACRYLIC: NV	AQUA ACRYLIC: AQ	TEAL ACRYLIC: TL	BURGUNDY ACRYLIC: BG

Vinyl Fabric

- Our most popular bimini top fabric
- Made of top-quality denim-backed vinyl, these economical tops are completely waterproof and easy to clean.



Fabric Colors and Color Codes

WHITE VINYL: WV	BLUE VINYL: BV
-----------------------	----------------------

How to Order

Step 1 — Plan Ahead

Pre-planning will help you select an Attwood Bimini Top that provides the correct area of shade and comfort for your boating enjoyment.

Select a Bimini Top size and plan a mounting point position so that the bimini will shade passengers when it is up and will also allow them to move when the frame is folded down.

When the frame is folded, you may need the optional Bimini Support Poles to elevate the frame and prevent it from obstructing the cockpit area (see Page 240).



Step 2 — Measure Your Boat

After determining your activity needs, measure your boat to determine the following dimensions:

Length — Measure the fore-to-aft length of the area you want to shade.

(Note: leave enough length behind and in front of the bimini top to secure the attachment straps).

Width — Measure the distance between mounting points where the frame attaches to the gunwale. **IMPORTANT:** Mounting points must be exactly the same distance fore and aft.

Height — Standing in the boat, measure straight up from the mounting point to reach the desired top height. This distance between mounting point and top height will be the frame height.

Consider how the top height will affect your movements. Be aware: the higher the top height, the less stable it may be on your boat.

Step 3 — Select A Frame and Fabric That Fits Your Boat

Frames and Fabric Tops are sold separately. Look at the charts in the next column to find the Fabric Code and Frame Size you want. Remember to add the Fabric Code to the end of the part number.

Order Example:

10340 = **Frame Only** that is 72" (6') long, 36" high, and 54"-60" wide.
 340BV = **Blue Vinyl Top Fabric** that is 72" (6') long and 54"-60" wide.
 340BL = **Blue Acrylic Top Fabric** that is 72" (6') long, and 54"-60" wide.
 10346XBL = **Pre-Assembled 3-Bow Frame and Blue Acrylic Top Fabric with Storage Boot** that is 72" (6') long, 48" high, and 54"-60" wide.